

**NC-1 HEADSET** 

**User Manual** 

# **Safety Instructions**

## **Hearing Safety:**


- 1.To avoid hearing damage, please do not listen for a long time at high volume.
- 2.Please use cautiously or stop using the headphones in potentially dangerous situations.
- 3.Do not use the headphones while driving.
- 4.For your safety, please do not turn the volume too high while running outside to ensure that you can hear your surroundings


## **Operation Safety:**

- 1. Avoid dropping.
- 2.Do not disassemble.
- 3.Keep away from children to avoid danger from improper use.
- 4.Do not submerge in water.
- 5.Do not use outdoors during thunderstorms.
- 6. Avoid operating in extreme temperatures. Please use the headphones within their operation temperature range: -15 °C (5 F) 55 °C (131 F).
- 7. Use original or certified cables for charging.
- 8.Do not use corrosive cleaner/oil to clean the headphones.



# At a Glance





## **How to Use**



3s Hold the power button for 3 seconds to turn the headphones on and to enter pairing mode. (the indicator light will turn blue)



(L) 3s Hold the Power Button for 3 seconds to turn the headphones off.



Press to adjust volume. Long press to skip to next/previous song.



Press the Multi-function Button to play/pause music.



Press the ANC Button to turn Active Noise Cancellation on/off (the indicator light will turn green).



Press the Multi-function Button to answer/end call.



Charging: Use the included cable to connect to the Charging Port of the device. Connect the other end of the charging cable to either a compute USB port or USB wall charger.

## **Functions**

#### **Easy Paring**

- 1. Hold the Power Button for 3 seconds to turn the headphones on and to enter pairing mode.
- Keep the headphones and your Bluetooth device as close as possible during the pairing process.
- 3. Turn on the Bluetooth function of your Bluetooth device. Search for the Bluetooth signal of the headphones on your Bluetooth device, and select 403A NC-1 to pair it with your Bluetooth device. The indicator light will slowly flash blue when the headphones are paired successfully.
- 4.If you are asked for a password/PIN code during the pairing procedure, enter "0000" (four zeros).

<sup>\*</sup>The picture is only provided for reference.
Please refer to the actual unit!

#### **ANC-Active Noise Cancelling:**

To turn on ANC, press the ANC Button; the green ANC Indicator light will turn on. To turn off ANC, press the ANC Button; the green ANC Indicator light will turn off.

#### AUX wired connection:

The headphones support AUX input for wired external audio source connection. Simply turn the headphones off and plug in the audio cable.

# **How to Wear**



# **Specification**

# **Indicator Light**

· Pairing: Red and blue lights flash alternately

· Paired: Blue light flashes

Playing:Blue light flashes slowly

• Charging: Red light turns on

•Full Charge: Red light turns off

· Battery Low: Red light turns on with voice prompt

· ANC On: Green light turns on.

# **Technical Specification**

• Product Name: 4O3A NC-1

• Bluetooth Version: v5.0

Speaker Unit: Φ40mm

· Magnet Type: Neodymium

• Sensitivity: 110±3db @1khz 1mv

• Nominal Impedance: 32Ω±10%

• Rang: 33ft/10m

· Battery: 750mah

• Voltage: 3.7v

Power: <100mw</li>Working Time: >25h

• Charging Time: 3~4h

Charging Way: Type C

• Frequency Response: 20hz-20khz

• Support: Hfp/hsp/a2dp/avrcp/sbc/mp3/aac

# **A&O**

# 1.Q: Why can't the headphones pair with my mobile phone?

A: Please check whether your headphones are in pairing mode or reconnection mode, check if the Bluetooth search function of your Bluetooth device is turned on, then go to the Bluetooth menu of your Bluetooth device, delete /forget the headphones and reconnect them.

2.Q: Why can't the headphones turn on?

A: Please double check the battery status of your headphones.

3.Q: Can I replace the battery in the headphones?

A: No. These headphones use a built-in non detachable Li-Polymer battery which can't be replaced.

4.Q: Can I use the headphones while driving?

A: For your safety, we strongly recommend you do not use headphones while driving so as to avoid distraction.

5.Q: Why do the headphones sometimes disc onnect from the Bluetooth device within 10 meters?

A: Please check if there is any metal material within a relatively close range that may be interfering with the Bluetooth connection. This may happen because Bluetooth is a radio technology which is sensitive to objects between the headphones and the connected devices.